



- EQUIPMENT SCHEDULE -

CODE	ITEM	DESCRIPTION	DISTANCE FROM MASTER LINE
A	FIRE CURTAIN	防火幕	
1	SCENERY BATTEN	景桿	75
2	TRUSS WASHING	景架/洗景車	26
			46
			70
B1	NO. 1 ELECTRIC * MOTORIZED * 11.1 & DRAW	1.1 電動 * 11.1 抽	135
3	SCENERY BATTEN WASHING	景桿洗景車	188
4	SCENERY BATTEN	景桿	209
5	SCENERY BATTEN	景桿	257
6	SCENERY BATTEN	景桿	270
7	SCENERY BATTEN	景桿	290
8	SCENERY BATTEN	景桿	310
9	SCENERY BATTEN WASHING	景桿洗景車	330
E2	NO. 2 ELECTRIC * MOTORIZED * 12 景架配桿	2.2 電動 * 12 抽	369
11	SCENERY BATTEN	景桿	411
12	SCENERY BATTEN WASHING	景桿洗景車	432
13	SCENERY BATTEN	景桿	472
14	SCENERY BATTEN	景桿	492
15	SCENERY BATTEN WASHING	景桿洗景車	493
16	SCENERY BATTEN	景桿	513
17	SCENERY BATTEN	景桿	534
18	SCENERY BATTEN	景桿	554
19	SCENERY BATTEN	景桿	574
E3	NO. 3 ELECTRIC * MOTORIZED * 13 景架配桿	3.3 電動 * 13 抽	620
20	SCENERY BATTEN	景桿	675
21	SCENERY BATTEN	景桿	695
22	SCENERY BATTEN WASHING	景桿洗景車	716
23	SCENERY BATTEN	景桿	736
24	SCENERY BATTEN	景桿	776
25	SCENERY BATTEN	景桿	796
26	SCENERY BATTEN WASHING	景桿洗景車	817
27	TRAVELER * MANUAL FLY & DRAW	中場車	858
28	SCENERY BATTEN	景桿	878
29	NO. 1 ELECTRIC * MOTORIZED * 11 景架配桿	1.1 電動 * 11 抽	918
30	SCENERY BATTEN WASHING	景桿洗景車	980
31	SCENERY BATTEN WASHING	景桿洗景車	1000
32	SCENERY BATTEN WASHING	景桿洗景車	1040
33	SCENERY BATTEN	景桿	1060
E5	NO. 5 ELECTRIC * CIV. LIGHTS * MOTORIZED	5.5 電動 * 5.5 抽	1102
			1140
34	NO. 6 ELECTRIC * MOTORIZED * 13 景架配桿	6.6 電動 * 13 抽	1350
35	NO. 6 ELECTRIC * MOTORIZED * 13 景架配桿	6.6 電動 * 13 抽	1380
36	SCENERY BATTEN WASHING	景桿洗景車	1384
37	TRUSS WASHING	景架/洗景車	1345
38	TRUSS WASHING	景架/洗景車	1353